

waterwitch Electronic Water Leveller

INSTALLATION

 Install Solenoid and Backflow Prevention Valve into water supply/fill line, ensuring arrows are pointing in the direction of the water flow. Connect Solenoid Cable to the Solenoid and Control Box.





NOTE

Sensor and Solenoid plugs must be inserted into the Water Witch Control Box with the fastening screws facing away from you.




waterwitch Electronic Water Leveller

Quick Start GUIDE

Sensor installed into balance line

- Attach Control Box to the wall in your equipment area, ensuring it is within reach of the power supply.
- Install Sensor into sensor line and set to the required water level height. Connect the Sensor Plug into the Control Box.



SET SENSOR LEVEL

- Fill the pool or water body to the required water level.
- Turn on power and water supply to Water Witch.
- Press MODE until you reach the SET LEVEL function.
- Confirm Sensor height is correct by checking the SCAN / FILL operation when lifting the Sensor up and down.
- Press ENTER to confirm.





SET OPERATING MODE

- Press MODE until you reach the SET TANK TYPE function.
- Press ↑ or ↓ to scroll to correct tank type that the sensor is monitoring.
- Press **ENTER** to confirm tank type.
- Press ↑ or ↓ to adjust water volume.
- Press ENTER to confirm volume.



Your Water Witch should now be set to operate reliably and effectively for many years.

Visit www.poolwaterwitch.com for a complete product guide, including a summary of available features, detailed installation and operational settings and troubleshooting help.